


2/3/4-Wire PT100/PT1000 Connections (5-Pin Plug)



Pin letters/numbers are moulded on the plug.

The above wiring diagram is for a
4-wire PT100/1000 sensor.

When connecting a 2-wire sensor, use pins E/1 & A/2

When connecting a 3-wire sensor, use pins E/1, A/2 & B/4

The wire colours mentioned above are commonly found on PT100 and PT1000 sensors. If different colours are used, please check connection details with your sensor supplier.